


# Sound Analysis Part 1



Step 1: A Chunk of sample is collected from the microphone for analysis

Step 2: Average Loudness of the Chunk is calculated and if it is greater than a threshold, then only further process the CHUNK, otherwise take another CHUNK

Step 3: Calculate the Fourier Transform of the CHUNK, this will find the amplitude of various frequencies in the CHUNK

Step 4: Our Frequency of interest is of the range about 1Khz to 5Khz, so we chop the FFT, this will also increase the computation speed

Step 5: Find the peaks of the FFT, using appropriate algorithm

Step 6: Not all peaks have same significance, so we calculate the peak prominence of each peak (how sharp is the peak from its base level), finally find the peak with highest peak prominence

Step 7: Check if the highest peak prominence is greater than a threshold, if yes then goto step 8, else take another CHUNK

Step 8: Add unity to the peckCount variable

Step 9: Amount of food, fed can be calculated by multiplying the peckCount by the estimated weight of fed during a single peck.